

## Bonn Wonder Knot "The knot that locks"

1. Place the two (2) open end cords on your left index finger as seen in **diagram 1**, with your thumb holding the two cords (A & B). Cord B should be longer than Cord A by approximately 6" in length.
2. Taking the cord closest to your body(B) as seen in **diagram 2**, wrap cord B as seen in **diagram 3** around your left index finger (moving toward the end of you finger), three times as seen in **diagram 4** (loosely). Make sure the cord is flush with each turn and not crossing over each other.
3. "The Most Important Step" as seen in **diagram 5** continuing with cord B make a loop and insert the loop of cord forward through the hole as you extract your left index finger back through the three coiled loops. Using your right fingers pull the loop (cord B) as shown down on cord A making a tight knot. Reminder: When pulling on the loop make sure you do not pull the end of cord B through the hole when you extract your index finger or you will end up in a Granny knot

After you have completed this portion of the "Bonn Wonder Knot" you are ready to secure the dry cleaning pad or any other cover that requires a tightening of cords. This knot works well on dry cleaning pads and prevents them from slipping when done correctly. The "Bonn Wonder Knot" will work on any lay down press, dry cleaning or laundry, and will ensure a secure tight fit for the cover.

